


Modbus/ Bacnet protocol



REGO 5200

Modbus protocol.....	2
Bacnet protocol.....	13
Reference list Modbus/ Bacnet.....	18

MODBUS PROTOCOL REGO 5200

REGO 5200, program version: 1.3-0-00 and later
Document version 1.3.1

Data types, Type, Scale, Offset & Function

Data types:

- L: Logic, range from False to True
- X: Index, range from 0 to 255
- I: Integer, range from -32767 to 32768
- R: Real, range from -3,3E38 to +3,3E38

Type:

- 0: No decoding.
- 1: LSB (byte) decodes to an Index variable.
- 2: LSB och MSB decodes to two consecutive Index variables.
- 3: Decodes to an Integer variable.
- 4: Decodes to a Real variable, Scale and Offset is used.
- 5: Two consecutive registers are decoded (binary) and transformed to a Real variable, Scale and Offset is used.
- 6: Two consecutive registers are decoded (IEEE) and transformed to a Real variable, Scale and Offset is used. *1
- 7: MSB (8bits) decodes to an Index variable.
- 8: LSB decodes to 8 consecutive Logic variables (False/True) *2
- 9: MSB decodes till 8 consecutive Logic variables (False/True) *2
- 10: The register (16 bits) decodes to 16 consecutive Logic variables (False/True)
- *1 Only applies to function 15, see "Function" below.
- *2 Not valid with function 6, see "Function" below.

Scale:

- 1: No scale
- 10: Scaled by factor ten, i.e. the read/written value are increased/decreased by a tenfold.
Example: The sensor value from T0 (27.3°C) is transferred as 273 and must be divided by ten before use.

Offset:

Zero point calibration.

Scale & Offset:

Reading registers Variable value = MODBUS value – actual value/Scale – Offset
Writing registers MODBUS value = (variable – actual value + Offset) * Scale

Function:

Explanation:

- 1: Read Coil StatusRead one or several consecutive logic registers
- 2: Read Input Status.....Read one or several consecutive logic registers
- 3: Read Holding Registers.....Read one or several consecutive analogue registers *1
- 4: Read Input RegistersRead one or several consecutive analogue registers *1
- 5: Force Single CoilWrite a logic value to a logic register
- 6: Preset Single Holding RegisterWrite a logic value to a logic register *1
- 7: Read Exception StatusRead 8 "Exception Status Coils", containing vendor specific data
- 15: Force Multiple Coils.....Write one or several consecutive logic values to consecutive logic registers
- 16: Preset Multiple Holding RegistersWrite one or several consecutive logic values to consecutive analogue registers *1
- *1 Dependent on type, See "Type" above.

Alarm status in REGO

- 1: Normal /No alarm
- 2: Blocked
- 3: Acknowledged
- 4: reserved
- 5: Returned (but not acknowledged)
- 6: reserved
- 7: Triggered

Acknowledge an alarm by sending the alarm number to address 40001. Await confirmation (255).
Alarms must be acknowledged one by one.

Addressing

There's a "De Facto-standard" that has been developed for easier integration.

Addressing is handled as follows:

The first variable of	Is addressed	Typical function(s)
COIL STATUS	00001	1, 5 (5=write)
INPUT STATUS	10001	2
HOLDING REGISTERS	40001	3, 6 (6=write)
INPUT REGISTERS	30001	4

Note that some systems can't handle the addressing above. Commonly a combination of function and an absolute reference are being used instead. Our address list consists of both alternatives.

Factory configuration

Modbus TCP

Settable	Factory	Range
Device ID:	1	0-255

Non settable

Port	502
------	-----

531

<ADDRESS LIST>

Read Digital Registers

INPUT STATUS Function 2

Address	De Facto-address	Type	Scale	Offs	Description
100	10001	*	*	*	Unit was just powered on
101	10002	*	*	*	Temporary protection
102	10003	*	*	*	Protection, needs reset
103	10004	*	*	*	Sum alarm, A
104	10005	*	*	*	Sum alarm, B
105	10006	*	*	*	DHW valve, 0=Heat, 1=DHW
106	10007	*	*	*	Digital input 1
107	10008	*	*	*	Digital input 2
108	10009	*	*	*	Digital input 3
109	10010	*	*	*	Digital input 4
110	10011	*	*	*	Digital input 5
111	10012	*	*	*	Digital input 6
112	10013	*	*	*	Digital input 7
113	10014	*	*	*	Digital input 8
114	10015	*	*	*	Digital output PC0
115	10016	*	*	*	Digital output EE1
116	10017	*	*	*	Digital output EE2
117	10018	*	*	*	Digital output VW1
118	10019	*	*	*	Digital output PC1
119	10020	*	*	*	Digital output PM1
120	10021	*	*	*	Digital output SSM
121	10022	*	*	*	Digital output compressor 1
122	10023	*	*	*	Digital output compressor 2
123	10024	*	*	*	Digital output ER3, wet injection
124	10025	*	*	*	Digital output ER4, wet injection

Read/Write Digital Registers

COIL STATUS Functions 1, 5 (5=write)

Address	De Facto-address	Type	Scale	Offs	Description
5	1	*	*	*	Thirdpartie compressor start enable (0=Auto, 1=Manual)
6	2	*	*	*	Thirdpartie compressor start (0=STOP, 1=Start) for compressor 1
7	3	*	*	*	Reserved for future use
8	4	*	*	*	Reserved for future use
9	5	*	*	*	Thirdpartie WatchDog reset (set to 1 within 5 minutes)
10	6	*	*	*	Override sensor inputs for T0 and TL1, apply values at 40002/3
11	7	*	*	*	Thirdpartie compressor start (0=STOP, 1=Start) for compressor 2
12	8	*	*	*	Thirdpartie flow temp. setpoint, apply value at 40053
13	9	*	*	*	External Circ. Pump DHW time channel (0=inactive, 1=active)
14	10	*	*	*	Heating hybrid control (0=inactive, 1=active)
15	11	*	*	*	DHW hybrid control (0=inactive, 1=active)

16	12	*	*	*	Override sensor input for T0, apply value at 40002
17	13	*	*	*	Override sensor input for TL1, apply value at 40003
18	14	*	*	*	Override sensor input for TC2, apply value at 40078

Read Analogue Registers, Type: 1=Index, 3=Integer, 4=Real

INPUT REGISTERS Function 4

Address	De Facto-address	Type	Scale	Offs	Description	
700	30001	1	1		Number of accessories	
701	30002	1	1		Additional heat type	0 = No additional heat, 1 = Step el. heat, 2 = Modulated add. heat, 3 = Mixed add. heat, 4 = District heating
702	30003	1	1		Enabled heat sources	0 = Only additional heat, 1 = Comp. + add. heat, 2 = Only compressor
703	30004	1	1		DHW sensor type	0 = No hot water, 1 = Local sensor, 2 = Communicated, 3 = Previous HP
704	30005	1	1		Additional heat: Current	demand in steps (0/1/2/3)
705	30006	1	1		Current demand compressor 1;	0=No demand, 1=Heat, 2=DHW, 3=Thermic disinfection, 4=Freeze protection. 5=External start, 6=Manual start
706	30007	5	1		Compressor 1 status	0 = OFF, 1 = DEPRESSURIZE, 2 = CLOSE_AND_WAIT, 3 = COMPRESSOR_START, 4 = COMPRESSOR_HEATUP, 5 = COMPRESSOR_RUN, 6= COMPRESSOR_STOP
707	30008	4	10		AI1, direct read	
708	30009	4	10		AI2, direct read	
709	30010	4	10		AI3, direct read	
710	30011	4	10		T0 sensor, heating system	
711	30012	4	10		TL1 sensor, outdoor direct	
712	30013	4	10		TL1 sensor, outdoor damped	
713	30014	4	10		TW1 sensor, DHW cylinder	
714	30015	4	10		TR6 sensor, hotgas compressor 1	
715	30016	4	10		TC1 sensor, additional heat	
716	30017	4	10		TC0 sensor, heating return	
717	30018	4	10		TB0 sensor, brine return	
718	30019	4	10		TB1 sensor, brine flow	
719	30020	4	10		T0 setpoint, Ymin	
720	30021	4	10		T0 setpoint, Ymax	
721	30022	4	10		T0 setpoint, DOT	
722	30023	4	10		T0 setpoint, heating system	
723	30024	4	10		x-coordinate 1	
724	30025	4	10		x-coordinate 2	
725	30026	4	10		x-coordinate 3	
726	30027	4	10		x-coordinate 4	
727	30028	4	10		x-coordinate 5	
728	30029	4	10		x-coordinate 6	
729	30030	4	10		x-coordinate 7	
730	30031	4	10		x-coordinate 8	
731	30032	4	10		x-coordinate 9	
732	30033	4	10		x-coordinate 10	
733	30034	4	10		x-coordinate 11	
734	30035	4	10		x-coordinate 12	
735	30036	4	10		Summer timer	
736	30037	4	10		Winter timer	
737	30038	4	10		Additional heat valve	
738	30039	4	1		Compressor 1	RunTimeMeter total h
739	30040	4	1		Compressor 1	RunTimeMeter total x
740	30041	4	1		Compressor 2	RunTimeMeter total h
741	30042	4	1		Compressor 2	RunTimeMeter total x
742	30043	4	1		Additional heat step1	RunTimeMeter total h
743	30044	4	1		Additional heat step1	RunTimeMeter total x
744	30045	4	1		Additional heat step2	RunTimeMeter total h
745	30046	4	1		Additional heat step2	RunTimeMeter total x

746	30047	4	1	Additonal heat step3	RunTimeMeter total h
747	30048	4	1	Additonal heat step3	RunTimeMeter total x
748	30049	4	1	PC1 circ. pump	RunTimeMeter total h
749	30050	4	1	PC1 circ. pump	RunTimeMeter total x
750	30051	4	1	Add.Heater valve	RunTimeMeter total h
751	30052	4	1	Add.Heater valve	RunTimeMeter total x
752	30053	4	1	Sum Alarm	RunTimeMeter total h
753	30054	4	1	Sum Alarm	RunTimeMeter total x
754	30055	4	1	DHW RunTimeMeter total h	
755	30056	4	1	DHW RunTimeMeter total x	
756	30057	4	1	Reserved for future use	RunTimeMeter total h
757	30058	4	1	Reserved for future use	RunTimeMeter total x
758	30059	4	1	Reserved for future use	RunTimeMeter total h
759	30060	4	1	Reserved for future use	RunTimeMeter total x
760	30061	4	1	PC0 RunTimeMeter total h	
761	30062	4	1	PC0 RunTimeMeter total x	
762	30063	4	1	PB3 RunTimeMeter total h	
763	30064	4	1	PB3 RunTimeMeter total x	
764	30065	4	1	Reserved for future use	
765	30066	4	1	Reserved for future use	
766	30067	4	10	Reserved for future use	
767	30068	4	10	Reserved for future use	
768	30069	4	10	Reserved for future use	
769	30070	4	1	Additional heat current start timer step 1, °minutes	
770	30071	4	1	Additional heat current start timer step 2, °minutes	
771	30072	4	1	Additional heat current start timer step 3, °minutes	
772	30073	4	1	Additional heat current stop timer step 2, °minutes	
773	30074	4	1	Additional heat current stop timer step 3, °minutes	
774	30075	4	1	Additional heat current stop timer step 3, °minutes	
775	30076	4	10	Reserved for future use	
776	30077	4	10	Reserved for future use	
777	30078	5	1	Compressor 2 status	0 = OFF, 1 = DEPRESSURIZE, 2 = CLOSE_AND_WAIT, 3 = COMPRESSOR_START, 4 = COMPRESSOR_HEATUP, 5 = COMPRESSOR_RUN, 6 = COMPRESSOR_STOP
778	30079	4	10	TC2 sensor, buffer temp.	
779	30080	5	1	FWS DHW circ. Pump	
780	30081	5	1	FWS diverter valve position	
781	30082	5	1	FWS heating water pump	
782	30083	5	1	FWS DHW circ. Pump total runtime	
783	30084	4	10	FWS cold water temp	
784	30085	4	10	FWS sensor, cold water temp	
785	30086	4	10	FWS sensor, DHW circulation temp	
786	30087	4	10	FWS sensor, DHW flow temp	
787	30088	4	10	FWS sensor, DHW return temp	
788	30089	4	10	FWS sensor, heating flow temp	
789	30090	4	10	FWS sensor, heating return temp	
790	30091	4	10	FWS sensor, water flow	
791	30092	4	100	FWS Heating water pump speed	
792	30093	1	1	Current demand compressor 2;	0=No demand, 1=Heat, 2=DHW, 3=Thermic disinfection, 4=Freeze protection. 5=External start, 6=Manual start
793	30094	4	10	Electric meter, kW	
794	30095	4	1	Electric meter, kWh	
795	30096	4	1	Electric meter, voltage L1	
796	30097	4	1	Electric meter, voltage L2	
797	30098	4	1	Electric meter, voltage L3	
798	30099	4	1	Electric meter, current L1	
799	30100	4	1	Electric meter, current L2	
800	30101	4	1	Electric meter, current L3	
801	30102	4	1	Currently produced power, kW	
802	30103	4	1	Produced heating energy, kWh	
803	30104	4	1	Produced dhw energy, kWh	
804	30105	4	1	Consumed energy, kWh	
805	30106	4	10	Reserved for future use	

806	30107	4	10	Reserved for future use
807	30108	4	10	Reserved for future use
808	30109	4	10	Reserved for future use
809	30110	4	10	Reserved for future use
810	30111	4	10	Reserved for future use
811	30112	4	10	Reserved for future use
812	30113	4	10	Reserved for future use
813	30114	4	10	Reserved for future use
814	30115	4	10	Reserved for future use
815	30116	4	10	Reserved for future use
816	30117	4	10	Reserved for future use
817	30118	4	10	Reserved for future use
818	30119	4	10	Reserved for future use
819	30120	4	10	Reserved for future use
820	30121	4	10	Reserved for future use
821	30122	4	10	Reserved for future use
822	30123	4	10	Reserved for future use
823	30124	4	10	Reserved for future use
824	30125	4	10	Reserved for future use
825	30126	4	10	Reserved for future use
826	30127	4	10	Reserved for future use
827	30128	4	10	Reserved for future use
828	30129	4	10	Reserved for future use
829	30130	4	10	Reserved for future use
830	30131	4	10	Reserved for future use
831	30132	4	10	Reserved for future use
832	30133	4	10	Reserved for future use
833	30134	4	10	Reserved for future use
834	30135	4	10	Reserved for future use
835	30136	4	10	Reserved for future use
836	30137	4	10	Reserved for future use
837	30138	4	10	Reserved for future use
838	30139	4	10	Reserved for future use
839	30140	4	10	Reserved for future use
840	30141	4	10	Reserved for future use
841	30142	4	10	Reserved for future use
842	30143	4	10	Reserved for future use
843	30144	4	10	Reserved for future use
844	30145	4	10	Reserved for future use
845	30146	4	10	Reserved for future use
846	30147	4	10	Reserved for future use
847	30148	4	10	Reserved for future use
848	30149	4	10	Reserved for future use
849	30150	4	10	Reserved for future use

A-alarms

850	30151	1	1	Alarm 1	Oper. error all PC1
851	30152	1	1	Alarm 2	Oper. error compr. and add. heat
852	30153	1	1	Alarm 3	Failure on sensor T0 and TC2
853	30154	1	1	Alarm 4	Sensor error TW4 DHW flowtemp
854	30155	1	1	Alarm 5	Failure PC4 Heating water pump
855	30156	1	1	Alarm 6	Reserved for future use
856	30157	1	1	Alarm 7	Reserved for future use
857	30158	1	1	Alarm 8	Reserved for future use
858	30159	1	1	Alarm 9	Reserved for future use

B-alarms

859	30160	1	1	Alarm 10	Failure on sensor TR3
860	30161	1	1	Alarm 11	Failure on sensor TW1
861	30162	1	1	Alarm 12	Failure on sensor TC0
862	30163	1	1	Alarm 13	Failure on sensor TC2
863	30164	1	1	Alarm 14	Failure on sensor TC3
864	30165	1	1	Alarm 15	Failure on sensor TB0
865	30166	1	1	Alarm 16	Failure on sensor TB1
866	30167	1	1	Alarm 17	Failure on sensor TR2
867	30168	1	1	Alarm 18	Failure on sensor TR5
868	30169	1	1	Alarm 19	Failure on sensor JR0
869	30170	1	1	Alarm 20	Failure on sensor JR1
870	30171	1	1	Alarm 21	Communication error with HP-card

871	30172	1	1	Alarm 22	Oper. error compressor 1
872	30173	1	1	Alarm 23	Oper. error compressor 2
873	30174	1	1	Alarm 24	Operating error PB3
874	30175	1	1	Alarm 25	Low temperature JR0
875	30176	1	1	Alarm 26	Tripped high pressure switch
876	30177	1	1	Alarm 27	Operating error PC0
877	30178	1	1	Alarm 28	Internal add. heater overheated
878	30179	1	1	Alarm 29	Mixed add. heater doesn't get warm
879	30180	1	1	Alarm 30	Compressor 1 does not start
880	30181	1	1	Alarm 31	Compressor 2 does not start
881	30182	1	1	Alarm 32	High pressure JR1
882	30183	1	1	Alarm 33	Low pressure JR1
883	30184	1	1	Alarm 34	Low temperature TB0
884	30185	1	1	Alarm 35	Low temperature TB1
885	30186	1	1	Alarm 36	High temperature TB0
886	30187	1	1	Alarm 37	High temperature TB1
887	30188	1	1	Alarm 38	High temperature TR6
888	30189	1	1	Alarm 39	High temperature TR7
889	30190	1	1	Alarm 40	High temperature TC1
890	30191	1	1	Alarm 41	High temperature TC0
891	30192	1	1	Alarm 42	Low temperature TR5
892	30193	1	1	Alarm 43	Problem with hot water production
893	30194	1	1	Alarm 44	Problem with VW1 3-way valve
894	30195	1	1	Alarm 45	Problem with Zx VWx 3-way valve
895	30196	1	1	Alarm 46	Start-up attempt interrupted
896	30197	1	1	Alarm 47	Wrong rotation compressor 1
897	30198	1	1	Alarm 48	Wrong rotation compressor 2
898	30199	1	1	Alarm 49	Operating error PC1
899	30200	1	1	Alarm 50	Compressor 1 overheated
900	30201	1	1	Alarm 51	Compressor 2 overheated
901	30202	1	1	Alarm 52	Communication error with accessory 1
902	30203	1	1	Alarm 53	Communication error with accessory 2
903	30204	1	1	Alarm 54	Communication error with accessory 3
904	30205	1	1	Alarm 55	Communication error with accessory 4
905	30206	1	1	Alarm 56	Communication error with accessory 5
906	30207	1	1	Alarm 57	Communication error with accessory 6
907	30208	1	1	Alarm 58	Communication error with accessory 7
908	30209	1	1	Alarm 59	Communication error with accessory 8
909	30210	1	1	Alarm 60	Communication error with accessory 9
910	30211	1	1	Alarm 61	Access.1 pump out of order
911	30212	1	1	Alarm 62	Access.2 pump out of order
912	30213	1	1	Alarm 63	Access.3 pump out of order
913	30214	1	1	Alarm 64	Access.4 pump out of order
914	30215	1	1	Alarm 65	Access.5 pump out of order
915	30216	1	1	Alarm 66	Access.6 pump out of order
916	30217	1	1	Alarm 67	Access.7 pump out of order
917	30218	1	1	Alarm 68	Access.8 pump out of order
918	30219	1	1	Alarm 69	Access.9 pump out of order
919	30220	1	1	Alarm 70	Communication error with Z1
920	30221	1	1	Alarm 71	Communication error with Z2
921	30222	1	1	Alarm 72	Communication error with Z3
922	30223	1	1	Alarm 73	Communication error with Z4
923	30224	1	1	Alarm 74	Communication error with Z5
924	30225	1	1	Alarm 75	Compressor 1 overcurrent
925	30226	1	1	Alarm 76	Compressor 1 stall
926	30227	1	1	Alarm 77	Bypass relay 1 failure
927	30228	1	1	Alarm 78	Wrong phase order on power supply
928	30229	1	1	Alarm 79	Wrong frequency order on power supply
929	30230	1	1	Alarm 80	Soft starter 1 failure
930	30231	1	1	Alarm 81	Fuse tripped for compressor 1
931	30232	1	1	Alarm 82	Fuse tripped for compressor 2
932	30233	1	1	Alarm 83	Wrong phase order to compressor 1
933	30234	1	1	Alarm 84	Wrong phase order to compressor 2
934	30235	1	1	Alarm 85	Wrong frequency to comperssor 1
935	30236	1	1	Alarm 86	Wrong frequency to comperssor 2
936	30237	1	1	Alarm 87	Compressor 2 overcurrent
937	30238	1	1	Alarm 88	Compressor 2 stall

938	30239	1	1	Alarm 89	Bypass relay 2 failiure
939	30240	1	1	Alarm 90	Soft starter 2 failiure
940	30241	1	1	Alarm 91	TW4 sensor error
941	30242	1	1	Alarm 92	Reserved for future use
942	30243	1	1	Alarm 93	TW5 sensor error
943	30244	1	1	Alarm 94	Low temperature TW6
944	30245	1	1	Alarm 95	Low temperature TW4
945	30246	1	1	Alarm 96	The software in the HP-card is too old
946	30247	1	1	Alarm 97	The SW in the Regin box is too old
947	30248	1	1	Alarm 98	TW2 sensor error
948	30249	1	1	Alarm 99	TW3 sensor error
949	30250	1	1	Alarm 100	GW0 sensor error
950	30251	1	1	Alarm 101	TW4 high temperature
951	30252	1	1	Alarm 102	TW2 low temperature
952	30253	1	1	Alarm 103	The software in the FWS is too old
953	30254	1	1	Alarm 104	The Regin SW is too old for the FWS
954	30255	1	1	Alarm 105	Communication error with FWS
955	30256	1	1	Alarm 106	Low temperature cooling system
956	30257	1	1	Alarm 107	Cooling system SSM alarm
957	30258	1	1	Alarm 108	Reserved for future use
958	30259	1	1	Alarm 109	Reserved for future use
959	30260	1	1	Alarm 110	Reserved for future use
960	30261	1	1	Alarm 111	Reserved for future use
961	30262	1	1	Alarm 112	Reserved for future use
962	30263	1	1	Alarm 113	Reserved for future use
963	30264	1	1	Alarm 114	Reserved for future use
964	30265	1	1	Alarm 115	Reserved for future use
965	30266	1	1	Alarm 116	Reserved for future use
966	30267	1	1	Alarm 117	Reserved for future use
967	30268	1	1	Alarm 118	Reserved for future use
968	30269	1	1	Alarm 119	Reserved for future use
969	30270	1	1	Alarm 120	Reserved for future use
970	30271	1	1	Alarm 121	Reserved for future use
971	30272	1	1	Alarm 122	Reserved for future use
972	30273	1	1	Alarm 123	Reserved for future use
973	30274	1	1	Alarm 124	Reserved for future use
974	30275	1	1	Alarm 125	Reserved for future use
975	30276	1	1	Alarm 126	Reserved for future use
976	30277	1	1	Alarm 127	Reserved for future use
977	30278	1	1	Alarm 128	Reserved for future use
978	30279	1	1	Alarm 129	Reserved for future use
979	30280	1	1	Alarm 130	Reserved for future use
980	30281	1	1	Alarm 131	Reserved for future use
981	30282	1	1	Alarm 132	Reserved for future use
982	30283	1	1	Alarm 133	Reserved for future use

C-alarms

983	30284	1	1	Alarm 134	Control unit restarted
984	30285	1	1	Alarm 135	High pressure JR1
985	30286	1	1	Alarm 136	Low pressure JR1
986	30287	1	1	Alarm 137	Low pressure JR0
987	30288	1	1	Alarm 138	Start-up attempt interrupted
988	30289	1	1	Alarm 139	Failure on sensor TB0
989	30290	1	1	Alarm 140	Failure on sensor TR3
990	30291	1	1	Alarm 141	Failure on sensor TR2
991	30292	1	1	Alarm 142	Failure on sensor TR6
992	30293	1	1	Alarm 143	Failure on sensor TR7
993	30294	1	1	Alarm 144	Failure on sensor TR8
994	30295	1	1	Alarm 145	Failure on sensor JR1
995	30296	1	1	Alarm 146	Failure on sensor JR2
996	30297	1	1	Alarm 147	Failure on sensor TC1
997	30298	1	1	Alarm 148	Failure on sensor TB1
998	30299	1	1	Alarm 149	Failure on sensor TC2
999	30300	1	1	Alarm 150	Failure on sensor TL1
1000	30301	1	1	Alarm 151	Compressor 1 does not start
1001	30302	1	1	Alarm 152	Compressor 2 does not start
1002	30303	1	1	Alarm 153	Oper. error compressor 1
1003	30304	1	1	Alarm 154	Oper. error compressor 2

1004	30305	1	1	Alarm 155	Wrong rotation compressor 1
1005	30306	1	1	Alarm 156	Wrong rotation compressor 2
1006	30307	1	1	Alarm 157	Compressor 1 overheated
1007	30308	1	1	Alarm 158	Compressor 2 overheated
1008	30309	1	1	Alarm 159	Replace memory battery
1009	30310	1	1	Alarm 160	Temporary error PB3 coll. circuit pump
1010	30311	1	1	Alarm 161	High temperature TR7
1011	30312	1	1	Alarm 162	Low temperature TR5
1012	30313	1	1	Alarm 163	Low temperature TR2
1013	30314	1	1	Alarm 164	Output in wrong pos after function test
1014	30315	1	1	Alarm 165	Hot water in emerg. oper.
1015	30316	1	1	Alarm 166	High temperature T0 flow
1016	30317	1	1	Alarm 167	Low temperature T0 flow
1017	30318	1	1	Alarm 168	Low temperature TW1 hot water
1018	30319	1	1	Alarm 169	High temperature TR6
1019	30320	1	1	Alarm 170	Tripped high pressure switch
1020	30321	1	1	Alarm 171	High temperature TC1
1021	30322	1	1	Alarm 172	High temperature TC0
1022	30323	1	1	Alarm 173	Low temperature TB0
1023	30324	1	1	Alarm 174	Low temperature TB1
1024	30325	1	1	Alarm 175	Low temp. diff. heat transfer fluid
1025	30326	1	1	Alarm 176	High temp. diff. heat transfer fluid
1026	30327	1	1	Alarm 177	High temp. diff. collector circuit
1027	30328	1	1	Alarm 178	Therm.disinfection unsuccessful
1028	30329	1	1	Alarm 179	Short oper.time in hot water mode
1029	30330	1	1	Alarm 180	Short oper.time in heating
1030	30331	1	1	Alarm 181	Temporary error PC0 heat carrier pump
1031	30332	1	1	Alarm 182	Failure on sensor T0
1032	30333	1	1	Alarm 183	High overheating TR5
1033	30334	1	1	Alarm 184	Too much refrigerant
1034	30335	1	1	Alarm 185	Lack of refrigerant
1035	30336	1	1	Alarm 186	Communication error with HP-card
1036	30337	1	1	Alarm 187	Accessory 1 temp. deviation
1037	30338	1	1	Alarm 188	Accessory 2 temp. deviation
1038	30339	1	1	Alarm 189	Accessory 3 temp. deviation
1039	30340	1	1	Alarm 190	Accessory 4 temp. deviation
1040	30341	1	1	Alarm 191	Accessory 5 temp. deviation
1041	30342	1	1	Alarm 192	Accessory 6 temp. deviation
1042	30343	1	1	Alarm 193	Accessory 7 temp. deviation
1043	30344	1	1	Alarm 194	Accessory 8 temp. deviation
1044	30345	1	1	Alarm 195	Accessory 9 temp. deviation
1045	30346	1	1	Alarm 196	Too low or too high voltage
1046	30347	1	1	Alarm 197	Too high temp softstart 1
1047	30348	1	1	Alarm 198	Too high temp softstart 2
1048	30349	1	1	Alarm 199	Failure on sensor TW6
1049	30350	1	1	Alarm 200	Failure on sensor TW7
1050	30351	1	1	Alarm 201	Oil equalization compressor 1
1051	30352	1	1	Alarm 202	Oil equalization compressor 2
1052	30353	1	1	Alarm 203	Failure on PW2 DHW circulation pump
1053	30354	1	1	Alarm 204	High temperature TW2
1054	30355	1	1	Alarm 205	Too long depressurize time
1055	30356	1	1	Alarm 206	High temperature TW6
1056	30357	1	1	Alarm 207	High temperature TW3
1057	30358	1	1	Alarm 208	Low voltage L1
1058	30359	1	1	Alarm 209	Low voltage L2
1059	30360	1	1	Alarm 210	Low voltage L3
1060	30361	1	1	Alarm 211	High current L1
1061	30362	1	1	Alarm 212	High current L2
1062	30363	1	1	Alarm 213	High current L3
1063	30364	1	1	Alarm 214	Wrong phase order
1064	30365	1	1	Alarm 215	Warmwater stopped by TC3
1065	30366	1	1	Alarm 216	Low temperature cooling system
1066	30367	1	1	Alarm 217	Cooling system startsignal alar
1067	30368	1	1	Alarm 218	Current to heat pump upper limit
1068	30369	1	1	Alarm 219	Evacuation and vacuum suction active
1069	30370	1	1	Alarm 220	Reserved for future use
1070	30371	1	1	Alarm 221	Reserved for future use

1071	30372	1	1	Alarm 222	Reserved for future use
1072	30373	1	1	Alarm 223	Reserved for future use
1073	30374	1	1	Alarm 224	Reserved for future use
1074	30375	1	1	Alarm 225	Reserved for future use
1075	30376	1	1	Alarm 226	Reserved for future use
1076	30377	1	1	Alarm 227	Reserved for future use
1077	30378	1	1	Alarm 228	Reserved for future use
1078	30379	1	1	Alarm 229	Reserved for future use
1079	30380	1	1	Alarm 230	Reserved for future use
1080	30381	1	1	Alarm 231	Reserved for future use
1081	30382	1	1	Alarm 232	Reserved for future use
1082	30383	1	1	Alarm 233	Reserved for future use
1083	30384	1	1	Alarm 234	Reserved for future use
1084	30385	1	1	Alarm 235	Reserved for future use
1085	30386	1	1	Alarm 236	Reserved for future use
1086	30387	1	1	Alarm 237	Reserved for future use
1087	30388	1	1	Alarm 238	Reserved for future use
1088	30389	1	1	Alarm 239	Reserved for future use
1089	30390	1	1	Alarm 240	Reserved for future use
1090	30391	1	1	Alarm 241	Reserved for future use
1091	30392	1	1	Alarm 242	Reserved for future use
1092	30393	1	1	Alarm 243	Reserved for future use
1093	30394	1	1	Alarm 244	Reserved for future use
1094	30395	1	1	Alarm 245	Reserved for future use
1095	30396	1	1	Alarm 246	Reserved for future use
1096	30397	1	1	Alarm 247	Reserved for future use
1097	30398	1	1	Alarm 248	Reserved for future use
1098	30399	4	1	Reserved for future use	
1099	30400	4	1	Reserved for future use	
1100	30401	4	1	Reserved for future use	
1101	30402	4	1	Reserved for future use	
1102	30403	4	1	Reserved for future use	
1103	30404	4	1	Reserved for future use	
1104	30405	4	1	Reserved for future use	
1105	30406	4	1	Reserved for future use	
1106	30407	4	1	Reserved for future use	
1107	30408	4	1	Reserved for future use	
1108	30409	4	1	Reserved for future use	
1109	30410	4	1	Reserved for future use	
1110	30411	4	1	Reserved for future use	
1111	30412	4	1	Reserved for future use	
1112	30413	4	1	Reserved for future use	
1113	30414	4	1	Reserved for future use	
1114	30415	4	1	Reserved for future use	
1115	30416	4	1	Reserved for future use	
1116	30417	4	1	Reserved for future use	
1117	30418	4	1	Reserved for future use	
1118	30419	4	1	Reserved for future use	
1119	30420	4	1	Reserved for future use	
1120	30421	4	1	Reserved for future use	
1121	30422	4	1	Reserved for future use	
1122	30423	4	1	Reserved for future use	
1123	30424	4	1	Reserved for future use	
1124	30425	4	1	Reserved for future use	
1125	30426	4	1	Reserved for future use	
1126	30427	4	10	TR8 sensor	
1127	30428	4	10	Current speed PC0	
1128	30429	4	10	Current speed PB3	
1129	30430	4	100	Reserved for future use	
1130	30431	4	100	Reserved for future use	
1131	30432	4	10	TC3 sensor, flow temp.	
1132	30433	5	1	Reserved for future use	
1133	30434	5	1	Reserved for future use	
1134	30435	4	10	TR3 sensor	
1135	30436	4	10	TR2 sensor	
1136	30437	4	10	TR5 sensor	
1137	30438	4	10	TR7 sensor, hotgas temperature compressor 2	

1138	30439	4	10	JR0 sensor, temperature
1139	30440	4	10	JR2 sensor, temperature
1140	30441	4	10	JR0 sensor, pressure
1141	30442	4	10	JR2 sensor, pressure
1142	30443	5	1	Reserved for future use
1143	30444	4	100	Reserved for future use
1144	30445	4	1	Reserved for future use
1145	30446	4	100	Reserved for future use
1146	30447	4	100	Reserved for future use
1147	30448	5	1	Reserved for future use
1148	30449	5	1	Reserved for future use
1149	30450	5	1	Reserved for future use
1150	30451	4	10	Reserved for future use
1151	30452	4	10	Reserved for future use
1152	30453	4	10	JR1 sensor, pressure
1153	30454	4	10	JR1 sensor, temperature

Read/Write Analogue Registers, Type: 1=Index, 3=Integer, 4=Real

HOLDING REGISTERS		Functions 3, 6 (6=write)			
Address	De Facto-address	Type	Scale	Offs	Description
500	40001	1	1	*	Alarm acknowledge (Alarm number)
501	40002	4	10	*	Sensor value to T0 in override mode
502	40003	4	10	*	Sensor value to TL1 in override mode
503	40004	4	10	*	Sensor value to TW1 in communicated mode
504	40005	4	10	*	y-coordinate 1
505	40006	4	10	*	y-coordinate 2
506	40007	4	10	*	y-coordinate 3
507	40008	4	10	*	y-coordinate 4
508	40009	4	10	*	y-coordinate 5
509	40010	4	10	*	y-coordinate 6
510	40011	4	10	*	y-coordinate 7
511	40012	4	10	*	y-coordinate 8
512	40013	4	10	*	y-coordinate 9
513	40014	4	10	*	y-coordinate 10
514	40015	4	10	*	y-coordinate 11
515	40016	4	10	*	y-coordinate 12
516	40017	4	10	*	Start of summer (17°)
517	40018	4	10	*	Start of summer (180m)
518	40019	4	10	*	Start of winter (15°)
519	40020	4	10	*	Start of winter (300m)
520	40021	4	10	*	Start of winter (7°)
521	40022	4	10	*	Hotwater start, only when TW1 setting = 2
522	40023	4	10	*	Hotwater stop, only when TW1 setting = 2
523	40024	4	10	*	Hotwater start, only when TW1 setting != 2
524	40025	4	10	*	Hotwater stop, only when TW1 setting != 2
525	40026	4	10	*	Additional heat, Start hysteresis
526	40027	4	10	*	Additional heat, Start step 1, °minutes
527	40028	4	10	*	Additional heat, Start step 2, °minutes
528	40029	4	10	*	Additional heat, Start step 3, °minutes
529	40030	4	10	*	Additional heat, Stop step 1, °minutes
530	40031	4	10	*	Additional heat, Stop step 2, °minutes
531	40032	4	10	*	Additional heat, Stop step 3, °minutes
532	40033	4	10	*	Additional heat, Thermostat alarm delay, minutes
533	40034	5	1	*	Reserved for future use
534	40035	5	1	*	Reserved for future use
535	40036	5	1	*	Reserved for future use
536	40037	5	1	*	Reserved for future use
537	40038	4	1	*	Reserved for future use
538	40039	4	1	*	Reserved for future use
539	40040	4	10	*	Reserved for future use
540	40041	4	10	*	Reserved for future use
541	40042	1	1	*	Reserved for future use
542	40043	1	1	*	Reserved for future use
543	40044	4	1	*	Reserved for future use
544	40045	1	1	*	Pump PB3, digital signal select 0 = Off, 1 = on, 2 = auto
545	40046	1	1	*	Pump PB3, analogue signal select, 0 = Off, 1 = man, 2=auto
546	40047	4	1	*	Pump PB3, analogue signal percentage

547	40048	4	1	*	Reserved for future use
548	40049	4	1	*	Reserved for future use
549	40050	1	1	*	Reserved for future use
550	40051	1	1	*	Reserved for future use
551	40052	4	1	*	Reserved for future use
552	40053	4	10	*	Flow temp. Setpoint in communicated mode
553	40054	5	1	*	FWS DHW circ. Pump off time holiday
554	40055	5	1	*	FWS DHW circ. Pump on time holiday
555	40056	5	1	*	FWS DHW circ. Pump off time weekday
556	40057	5	1	*	FWS DHW circ. Pump on time weekday
557	40058	4	10	*	FWS Alarm limit high DHW circ. Temp.
558	40059	4	10	*	FWS Alarm limit high DHW temp
559	40060	4	10	*	FWS Alarm limit low DHW circ. Temp.
560	40061	4	10	*	FWS Alarm limit low DHW temp
561	40062	4	10	*	FWS heating water pump DHW temp. Setpoint
562	40063	4	1	*	FWS setpoint
563	40064	1	1	*	Time channel start time weekdays
564	40065	1	1	*	Time channel stop time weekdays
565	40066	5	1	*	Time channel offset weekdays
566	40067	1	1	*	Time channel start time weekends
567	40068	1	1	*	Time channel stop time weekends
568	40069	5	1	*	Time channel offset weekends
569	40070	4	10	*	Offset against TW1, when first compressor will shut down DHW
570	40071	1	1	*	Activation time for DHW circulation time channel during weekdays
571	40072	1	1	*	Deactivation time for DHW circulation time channel during weekdays
572	40073	1	1	*	Reserved for future use
573	40074	1	1	*	Activation time for DHW circulation time channel during weekends
574	40075	1	1	*	Deactivation time for DHW circulation time channel during weekends
575	40076	4	100	*	Electricity price per kWh
576	40077	4	100	*	Additional heat price per kWh
577	40078	4	10	*	Sensor value to TC2 in override mode
578	40079	4	1	*	Pump PB3 analogue value when compressor is not running
579	40080	1	1	*	Pump PB3, activate pump when compressor is not running
580	40081	1	1	*	FWS DHW circ. Pump timechannel activation

End

Remarks

- *0 These settings requires that the watchdog has been reset, or else they will be ignored.
- *1 0=None, 1=Internal, 2=Modulated, 3=Shunted, 4=District heating.
- *2 0=Heater, 1=Compressor and Heater, 2=Compressor.
- *3 0=None, 1=Local sensor, 2=Communicated sensor value, 3=Value from previous heat pump.
- *4 0=No demand, 1=Heat, 2=DHW, 3=Thermal disinfection, 4=Freeze protection, 5=External start, 6=Manual start.
- *5 0=Off, 1=Starting, 2=Temperature check, 3=Rotation control, 4=Running, 5=Stopping.
- *6 Available as remote I/O PT1000 in a heat pump where the input is not in use.
- *7 Valid only when TW1 sensor is selected as communicated.
- *8 Valid only when TW1 sensor is selected as local or previous HP.

BACNET PROTOCOL REGO 5200

REGO 5200, program version: 1.3-0-00 and later
 Document version 1.3.1-01

device- object- instance	object- name	object- type	object- instance	description	settable
2001	alarmAcknowledge	2	2	Alarm acknowledge, write alarm numer to acknowledge alarm	Y
2001	externalT0SensorValue	2	3	T0 sensor value in override mode	Y
2001	externalTL1SensorValue	2	4	TL1 sensor value in override mode	Y
2001	externalTW1SensorValue	2	5	TW1 sensor value in override mode	Y
2001	Y_coordinate1	2	6	The heat curves value if the outdoor temperature is 20 degrees	Y
2001	Y_coordinate2	2	7	The heat curves value if the outdoor temperature is 15 degrees	Y
2001	Y_coordinate3	2	8	The heat curves value if the outdoor temperature is 10 degrees	Y
2001	Y_coordinate4	2	9	The heat curves value if the outdoor temperature is 5 degrees	Y
2001	Y_coordinate5	2	10	The heat curves value if the outdoor temperature is 0 degrees	Y
2001	Y_coordinate6	2	11	The heat curves value if the outdoor temperature is -5 degrees	Y
2001	Y_coordinate7	2	12	The heat curves value if the outdoor temperature is -10 degrees	Y
2001	Y_coordinate8	2	13	The heat curves value if the outdoor temperature is -15 degrees	Y
2001	Y_coordinate9	2	14	The heat curves value if the outdoor temperature is -20 degrees	Y
2001	Y_coordinate10	2	15	The heat curves value if the outdoor temperature is -25 degrees	Y
2001	Y_coordinate11	2	16	The heat curves value if the outdoor temperature is -30 degrees	Y
2001	Y_coordinate12	2	17	The heat curves value if the outdoor temperature is -35 degrees	Y
2001	summerOperationTemperature	2	18	Start of summer operation temperature	Y
2001	summerOperationTime	2	19	Start of summer operation time	Y
2001	winterOperationTemperature	2	20	Start of winter operation temperature	Y
2001	winterOperationTime	2	21	Start of winter operation time	Y
2001	winterOperationNowTemperature	2	22	Imidiata start of winter operation temperature	Y
2001	dhwStartTemperatureCom	2	23	DHW TW1 start temperature if communicated TW1 sensor is used	Y
2001	dhwStopTemperatureCom	2	24	DHW TW1 stop temperature if communicated TW1 sensor is used	Y
2001	dhwStartTemperature	2	25	DHW TW1 start temperature if local TW1 sensor is used	Y
2001	dhwStopTemperature	2	26	DHW TW1 stop temperature if local TW1 sensor is used	Y
2001	addHeatStartHysteresis	2	27	additional heat start hysteresis	Y
2001	addHeatStartTime1	2	28	additional heat start time in degree minutes for step1	Y
2001	addHeatStartTime2	2	29	additional heat start time in degree minutes for step2	Y
2001	addHeatStartTime3	2	30	additional heat start time in degree minutes for step3	Y
2001	addHeatStopTime1	2	31	additional heat stop time in degree minutes for step1	Y
2001	addHeatStopTime2	2	32	additional heat stop time in degree minutes for step2	Y
2001	addHeatStopTime3	2	33	additional heat stop time in degree minutes for step3	Y
2001	addHeatAlarmDelayTime	2	34	Delay time for additional heat alarm	Y
2001	flowTemperatureSetpointCom	2	35	The flow temperature setpoint in communicated mode	Y
2001	fwsDhwCircPumpOffTimeWeekend	2	36	The FWS DHW circ. pump off time during weekends	Y
2001	fwsDhwCircPumpOnTimeWeekend	2	37	The FWS DHW circ. pump on time during weekends	Y
2001	fwsDhwCircPumpOffTimeWeekday	2	38	The FWS DHW circ. pump off time during weekdays	Y
2001	fwsDhwCircPumpOnTimeWeekday	2	39	The FWS DHW circ. pump on time during weekdays	Y
2001	fwsDhwAlarmHighDhwCircTemperatureLimit	2	40	The FWS Alarm limit for high DHW circ. temperature	Y
2001	fwsDhwAlarmHighDhwTemperatureLimit	2	41	The FWS Alarm limit for high DHW temperature	Y
2001	fwsDhwAlarmLowDhwCircTemperatureLimit	2	42	The FWS Alarm limit for low DHW circ. temperature	Y
2001	fwsDhwAlarmLowDhwTemperatureLimit	2	43	The FWS Alarm limit for low DHW temperature	Y
2001	fwsDhwHeatingWaterPumpTemperatureSetpoint	2	44	The FWS heating water pump DHW temperature setpoint	Y
2001	fwsDhwSetpoint	2	45	The FWS DHW setpoint	Y
2001	hybridControlElectricityPrice	2	64	Electricity price per kWh	Y

2001	hybridControlAddHeatPrice	2	65	Additional heat price per kWh	Y
2001	analogInput1	2	67	AI1, direct read (T0)	N
2001	analogInput2	2	68	AI2, direct read (TL1)	N
2001	analogInput3	2	69	AI3, direct read (TW1)	N
2001	sensorT0	2	70	T0 sensor, heating system	N
2001	sensorTL1Raw	2	71	TL1 sensor, outdoor direct	N
2001	sensorTL1	2	72	TL1 sensor, outdoor damped	N
2001	sensorTW1	2	73	TW1 sensor, DHW cylinder	N
2001	sensorTR6	2	74	TR6 sensor, hotgas	N
2001	sensorTC1	2	75	TC1 sensor, additional heat	N
2001	sensorTC0	2	76	TC0 sensor, heating return	N
2001	sensorTB0	2	77	TB0 sensor, brine return	N
2001	sensorTB1	2	78	TB1 sensor, brine flow	N
2001	sensorTC2	2	79	TC2 sensor, buffer temperature	N
2001	sensorTR8	2	80	TR8 sensor	N
2001	sensorTC3	2	81	TC3 sensor, flow temperature	N
2001	sensorTR3	2	82	TR3 sensor	N
2001	sensorTR2	2	83	TR2 sensor	N
2001	sensorTR5	2	84	TR5 sensor	N
2001	sensorTR7	2	85	TR7 sensor, hotgas	N
2001	sensorJR0Temperature	2	86	JR0 sensor, temperature	N
2001	sensorJR0Pressure	2	87	JR0 sensor, pressure in bar	N
2001	sensorJR1Temperature	2	88	JR1 sensor, temperature	N
2001	sensorJR1Pressure	2	89	JR1 sensor, pressure in bar	N
2001	sensorJR2Temperature	2	90	JR2 sensor, temperature	N
2001	sensorJR2Pressure	2	91	JR2 sensor, pressure in bar	N
2001	flowTemperatureSetpoint	2	92	Flow temperature setpoint for T0	N
2001	addHeatValve	2	93	Output for the additional heater valve	N
2001	runTimeMeeterCompressor1	2	94	Run time meeter for compressor 1	N
2001	runTimeMeeterCompressor2	2	95	Run time meeter for compressor 2	N
2001	runTimeMeeterAddHeatStep1	2	96	Run time meeter for add heat step 1	N
2001	runTimeMeeterAddHeatStep2	2	97	Run time meeter for add heat step 2	N
2001	runTimeMeeterAddHeatStep3	2	98	Run time meeter for add heat step 3	N
2001	runTimeMeeterPC1	2	99	Run time meeter for PC1 circ. pump	N
2001	runTimeMeeterAddHeatValve	2	100	Run time meeter for Additional heater valve	N
2001	runTimeMeeterSummaryAlarm	2	101	Run time meeter for the summary alarm	N
2001	runTimeMeeterDHW	2	102	Run time meeter for DHW	N
2001	runTimeMeeterPC0	2	103	Run time meeter for PC0 heating pump	N
2001	runTimeMeeterPB3	2	104	Run time meeter for PB3 brine pump	N
2001	PC0Output	2	105	Current speed PC0	N
2001	PB3Output	2	106	Current speed PB3	N
2001	fwsDhwCircPump	2	107	FWS DHW circ. Pump	N
2001	fwsDiverterValvePosition	2	108		N
2001	fwsHeatingWaterPump	2	109		N
2001	fwsRunTimeMeeterDhwCirculationPump	2	110		N
2001	fwsColdWaterTemperature	2	111		N
2001	fwsSensorColdWaterTemperature	2	112		N
2001	fwsSensorDhwCircTemperature	2	113		N
2001	fwsSensorDhwFlowTemperature	2	114		N
2001	fwsSensorDhwReturnTemperature	2	115		N
2001	fwsSensorHeatingFlowTemperature	2	116		N
2001	fwsSensorHeatingReturnTemperature	2	117		N

2001	fwsSensorWaterFlow	2	118		N
2001	fwsHeatingWaterPumpSpeed	2	119		N
2001	summaryAlarmC_1	2	120		N
2001	summaryAlarmC_2	2	121		N
2001	summaryAlarmC_3	2	122		N
2001	summaryAlarmC_4	2	123		N
2001	summaryAlarmC_5	2	124		N
2001	externalCompressorStartEnable	5	1	Thirdpartie compressor start (0=Auto, 1=RUN)	Y
2001	externalStartCompressor1	5	2	Thirdpartie compressor allow (0=STOP, 1=Auto) for compressor1	Y
2001	externalStartCompressor2	5	3	Thirdpartie compressor allow (0=STOP, 1=Auto) for compressor2	Y
2001	resetWatchdog	5	4	Thirdpartie WatchDog reset (5 minutes)	Y
2001	CommunicatedSensors	5	5	Override sensor inputs for T0 and TL1	Y
2001	communicatedFlowTempSetpoint	5	6	Override sensor input for T0	Y
2001	bootMode	5	7	Unit was just powered on	N
2001	temporaryProtection	5	8	Temporary protection triggered	N
2001	blockingProtection	5	9	blocking protection, needs reset	N
2001	sumAlarmA	5	10	summary alarm, A	N
2001	sumAlarmB	5	11	summary alarm, B	N
2001	dhwValve	5	12	DHW valve VW1	N
2001	digitalInput1	5	13	Digital input 1	N
2001	digitalInput2	5	14	Digital input 2	N
2001	digitalInput3	5	15	Digital input 3	N
2001	digitalInput4	5	16	Digital input 4	N
2001	digitalInput5	5	17	Digital input 5	N
2001	digitalInput6	5	18	Digital input 6	N
2001	digitalInput7	5	19	Digital input 7	N
2001	digitalInput8	5	20	Digital input 8	N
2001	digitalOutputPC0	5	21	Digital output PC0	N
2001	digitalOutputEE1	5	22	Digital output EE1	N
2001	digitalOutputEE2	5	23	Digital output EE2	N
2001	digitalOutputVW1	5	24	Digital output VW1	N
2001	digitalOutputPC1	5	25	Digital output PC1	N
2001	digitalOutputPM1	5	26	Digital output PM1	N
2001	digitalOutputSSM	5	27	Digital output SSM	N
2001	digitalOutputCompressor1	5	28	Digital output compressor1	N
2001	digitalOutputCompressor2	5	29	Digital output compressor2	N
2001	digitalOutputER3	5	30	Digital output ER3	N
2001	digitalOutputER4	5	31	Digital output ER4	N
2001	externalDhwCircPumpTimeChannelEnable	5	32	External Circ. Pump DHW time channel (0=inactive, 1=active)	Y
2001	hybridControlHeatingEnable	5	33	Heating hybrid control (0=inactive, 1=active)	Y
2001	hybridControlDhwEnable	5	34	DHW hybrid control (0=inactive, 1=active)	Y
2001	AlaAcknow	19	2	Alarm acknowledge, write alarm numer to acknowledge alarm	Y
2001	fwsDhwCircPumpOffTimeWeekend1	19	3	The FWS DHW curc. pump off time during weekends	Y
2001	numberOfStandardAccessories	19	10	Number of standard accessories installed	N
2001	additionalHeaterType	19	11	Which type of additional heat is installed	N
2001	selectCompAddHeat	19	12	Which combination of heating is used	N
2001	warmWaterType	19	13	Which type of warmwater sensor is used	N
2001	addHeatDemand	19	14	Current additional heat demand	N
2001	compressor1Demand	19	15	Current demand state of compressor 1	N
2001	compressor1RunState	19	16	Current run state of compressor 1	N
2001	compressor2Demand	19	17	Current demand state of compressor 2	N
2001	compressor2RunState	19	18	Current run state of compressor 2	N
2001	Alarm1	19	19	Oper. error all PC1	N
2001	Alarm2	19	20	Oper. error compr. and add. heat	N
2001	Alarm3	19	21	Failure on sensor T0 and TC2	N
2001	Alarm4	19	22	Sensor error TW4 DHW flowtemp	N
2001	Alarm5	19	23	Failure PC4 Heating water pump	N
2001	Alarm10	19	24	Failure on sensor TR3	N
2001	Alarm11	19	25	Failure on sensor TW1	N

2001	Alarm12	19	26	Failure on sensor TC0	N
2001	Alarm13	19	27	Failure on sensor TC2	N
2001	Alarm14	19	28	Failure on sensor TC3	N
2001	Alarm15	19	29	Failure on sensor TB0	N
2001	Alarm16	19	30	Failure on sensor TB1	N
2001	Alarm17	19	31	Failure on sensor TR2	N
2001	Alarm18	19	32	Failure on sensor TR5	N
2001	Alarm19	19	33	Failure on sensor JR0	N
2001	Alarm20	19	34	Failure on sensor JR1	N
2001	Alarm21	19	35	Communication error with HP-card	N
2001	Alarm22	19	36	Oper. error compressor 1	N
2001	Alarm23	19	37	Oper. error compressor 2	N
2001	Alarm24	19	38	Operating error PB3	N
2001	Alarm25	19	39	Low temperature JR0	N
2001	Alarm26	19	40	Tripped high pressure switch	N
2001	Alarm27	19	41	Operating error PC0	N
2001	Alarm28	19	42	Internal add. heater overheated	N
2001	Alarm29	19	43	Mixed add. heater doesn't get warm	N
2001	Alarm30	19	44	Compressor 1 does not start	N
2001	Alarm31	19	45	Compressor 2 does not start	N
2001	Alarm32	19	46	High pressure JR1	N
2001	Alarm33	19	47	Low pressure JR1	N
2001	Alarm34	19	48	Low temperature TB0	N
2001	Alarm35	19	49	Low temperature TB1	N
2001	Alarm36	19	50	High temperature TB0	N
2001	Alarm37	19	51	High temperature TB1	N
2001	Alarm38	19	52	High temperature TR6	N
2001	Alarm39	19	53	High temperature TR7	N
2001	Alarm40	19	54	High temperature TC1	N
2001	Alarm41	19	55	High temperature TC0	N
2001	Alarm42	19	56	Low temperature TR5	N
2001	Alarm43	19	57	Problem with hot water production	N
2001	Alarm44	19	58	Problem with VW1 3-way valve	N
2001	Alarm45	19	59	Problem with Zx VWx 3-way valve	N
2001	Alarm46	19	60	Start-up attempt interrupted	N
2001	Alarm47	19	61	Wrong rotation compressor 1	N
2001	Alarm48	19	62	Wrong rotation compressor 2	N
2001	Alarm49	19	63	Operating error PC1	N
2001	Alarm50	19	64	Compressor 1 overheated	N
2001	Alarm51	19	65	Compressor 2 overheated	N
2001	Alarm52	19	66	Communication error with accessory 1	N
2001	Alarm53	19	67	Communication error with accessory 2	N
2001	Alarm54	19	68	Communication error with accessory 3	N
2001	Alarm55	19	69	Communication error with accessory 4	N
2001	Alarm56	19	70	Communication error with accessory 5	N
2001	Alarm57	19	71	Communication error with accessory 6	N
2001	Alarm58	19	72	Communication error with accessory 7	N
2001	Alarm59	19	73	Communication error with accessory 8	N
2001	Alarm60	19	74	Communication error with accessory 9	N
2001	Alarm61	19	75	Access.1 pump out of order	N
2001	Alarm62	19	76	Access.2 pump out of order	N
2001	Alarm63	19	77	Access.3 pump out of order	N
2001	Alarm64	19	78	Access.4 pump out of order	N
2001	Alarm65	19	79	Access.5 pump out of order	N
2001	Alarm66	19	80	Access.6 pump out of order	N
2001	Alarm67	19	81	Access.7 pump out of order	N
2001	Alarm68	19	82	Access.8 pump out of order	N
2001	Alarm69	19	83	Access.9 pump out of order	N
2001	Alarm70	19	84	Communication error with Z1	N
2001	Alarm71	19	85	Communication error with Z2	N
2001	Alarm72	19	86	Communication error with Z3	N
2001	Alarm73	19	87	Communication error with Z4	N
2001	Alarm74	19	88	Communication error with Z5	N
2001	Alarm75	19	89	Compressor 1 overcurrent	N
2001	Alarm76	19	90	Compressor 1 stall	N
2001	Alarm77	19	91	Bypass relay 1 failure	N
2001	Alarm78	19	92	Wrong phase order on power supply	N

2001	Alarm79	19	93	Wrong frequency order on power supply	N
2001	Alarm80	19	94	Soft starter 1 failiure	N
2001	Alarm81	19	95	Fuse tripped for compressor 1	N
2001	Alarm82	19	96	Fuse tripped for compressor 2	N
2001	Alarm83	19	97	Wrong phase order to compressor 1	N
2001	Alarm84	19	98	Wrong phase order to compressor 2	N
2001	Alarm85	19	99	Wrong frequency to comperssor 1	N
2001	Alarm86	19	100	Wrong frequency to comperssor 2	N
2001	Alarm87	19	101	Compressor 2 overcurrent	N
2001	Alarm88	19	102	Compressor 2 stall	N
2001	Alarm89	19	103	Bypass relay 2 failiure	N
2001	Alarm90	19	104	Soft starter 2 failiure	N
2001	Alarm91	19	105	TW4 sensor error	N
2001	Alarm93	19	107	TW5 sensor error	N
2001	Alarm94	19	108	Low temperature TW6	N
2001	Alarm95	19	109	Low temperature TW4	N
2001	Alarm96	19	110	The software in the HP-card is too old	N
2001	Alarm97	19	111	The SW in the Regin box is too old	N
2001	Alarm98	19	112	TW2 sensor error	N
2001	Alarm99	19	113	TW3 sensor error	N
2001	Alarm100	19	118	GW0 sensor error	N
2001	Alarm101	19	119	TW4 high temperature	N
2001	Alarm102	19	120	TW2 low temperature	N
2001	Alarm103	19	121	The software in the FWS is too old	N
2001	Alarm104	19	122	The Regin SW is too old for the FWS	N
2001	Alarm105	19	123	Communication error with FWS	N

Reference list Modbus/ Bacnet

Modbus Address	Bacnet object name	Bacnet object instance
5	externalCompressorStartEnable	1
6	externalStartCompressor1	2
7		
8		
9	resetWatchdog	4
10	CommunicatedSensors	5
11	externalStartCompressor2	3
12	communicatedFlowTempSetpoint	6
13	externalDhwCircPumpTimeChannelEnable	32
14	hybridControlHeatingEnable	33
15	hybridControlDhwEnable	34
16		
17		
18		
100	bootMode	7
101	temporaryProtection	8
102	blockingProtection	9
103	sumAlarmA	10
104	sumAlarmB	11
105	dhwValve	12
106	digitalInput1	13
107	digitalInput2	14
108	digitalInput3	15
109	digitalInput4	16
110	digitalInput5	17
111	digitalInput6	18
112	digitalInput7	19
113	digitalInput8	20
114	digitalOutputPC0	21
115	digitalOutputEE1	22
116	digitalOutputEE2	23
117	digitalOutputVW1	24
118		
119		
120		
121	digitalOutputCompressor1	28
122	digitalOutputCompressor2	29
123	digitalOutputER3	30
124	digitalOutputER4	31
500	AlaAcknow	2
501	externalT0SensorValue	3
502	externalTL1SensorValue	4
503	externalTW1SensorValue	5
504	Y_coordinate1	6
505	Y_coordinate2	7
506	Y_coordinate3	8
507	Y_coordinate4	9
508	Y_coordinate5	10
509	Y_coordinate6	11
510	Y_coordinate7	12
511	Y_coordinate8	13
512	Y_coordinate9	14
513	Y_coordinate10	15
514	Y_coordinate11	16
515	Y_coordinate12	17
516	summerOperationTemperature	18
517	summerOperationTime	19
518	winterOperationTemperature	20
519	winterOperationTime	21
520	winterOperationNowTemperature	22
521	dhwStartTemperatureCom	23
522	dhwStopTemperatureCom	24
523	dhwStartTemperature	25

524	dhwStopTemperature	26
525	addHeatStartHysteresis	27
526	addHeatStartTime1	28
527	addHeatStartTime2	29
528	addHeatStartTime3	30
529	addHeatStopTime1	31
530	addHeatStopTime2	32
531	addHeatStopTime3	33
532	addHeatAlarmDelayTime	34
533		
534		
535		
536		
537		
538		
539		
540		
541		
542		
543		
544		
545		
546		
547		
548		
549		
550		
551		
552	flowTemperatureSetpointCom	35
553	fwsDhwCircPumpOffTimeWeekend	36
554	fwsDhwCircPumpOnTimeWeekend	37
555	fwsDhwCircPumpOffTimeWeekday	38
556	fwsDhwCircPumpOnTimeWeekday	39
557	fwsDhwAlarmHighDhwCircTemperatureLimit	40
558	fwsDhwAlarmHighDhwTemperatureLimit	41
559	fwsDhwAlarmLowDhwCircTemperatureLimit	42
560	fwsDhwAlarmLowDhwTemperatureLimit	43
561	fwsDhwHeatingWaterPumpTemperatureSetpoint	44
562	fwsDhwSetpoint	45
563		
564		
565		
566		
567		
568		
569		
570		
571		
572		
573		
574		
575	hybridControlElectricityPrice	64
576	hybridControlAddHeatPrice	65
577		
578		
579		
580		
700	numberOfStandardAccessories	10
701	additionalHeaterType	11
702	selectCompAddHeat	12
703	warmWaterType	13
704		

705	compressor1Demand	15
706	compressor1RunState	16
707	analogInput1	67
708	analogInput2	68
709	analogInput3	69
710	sensorT0	70
711	sensorTL1Raw	71
712	sensorTL1	72
713	sensorTW1	73
714	sensorTR6	74
715	sensorTC1	75
716	sensorTC0	76
717	sensorTB0	77
718	sensorTB1	78
719		
720		
721		
722	flowTemperatureSetpoint	92
723		
724		
725		
726		
727		
728		
729		
730		
731		
732		
733		
734		
735		
736		
737	addHeatValve	93
738	runTimeMeeterCompressor1	94
739		
740	runTimeMeeterCompressor2	95
741		
742	runTimeMeeterAddHeatStep1	96
743		
744	runTimeMeeterAddHeatStep2	97
745		
746	runTimeMeeterAddHeatStep3	98
747		
748	runTimeMeeterPC1	99
749		
750	runTimeMeeterAddHeatValve	100
751		
752	runTimeMeeterSummaryAlarm	101
753		
754	runTimeMeeterDHW	102
755		
756		
757		
758		
759		
760	runTimeMeeterPC0	103
761		
762	runTimeMeeterPB3	104
763		
764		
765		
766		
767		

768		
769		
770		
771		
772		
773		
774		
775		
776		
777	compressor2RunState	18
778	sensorTC2	79
779	fwsDhwCircPump	107
780	fwsDiverterValvePosition	108
781	fwsHeatingWaterPump	109
782	fwsRunTimeMeeterDhwCirculationPump	110
783	fwsColdWaterTemperature	111
784	fwsSensorColdWaterTemperature	112
785	fwsSensorDhwCircTemperature	113
786	fwsSensorDhwFlowTemperature	114
787	fwsSensorDhwReturnTemperature	115
788	fwsSensorHeatingFlowTemperature	116
789	fwsSensorHeatingReturnTemperature	117
790	fwsSensorWaterFlow	118
791	fwsHeatingWaterPumpSpeed	119
792	compressor2Demand	17
793		
794		
795		
796		
797		
798		
799		
800		
801		
802		
803		
804		
805		
806		
807		
808		
809		
810		
811		
812		
813		
814		
815		
816		
817		
818		
819		
820		
821		
822		
823		
824		
825		
826		
827		
828		
829		
830		
831		

832		
833		
834		
835		
836		
837		
838		
839		
840		
841		
842		
843		
844		
845		
846		
847		
848		
849		
850	Alarm1	19
851	Alarm2	20
852	Alarm3	21
853	Alarm4	22
854	Alarm5	23
855		
856		
857		
858		
859	Alarm10	24
860	Alarm11	25
861	Alarm12	26
862	Alarm13	27
863	Alarm14	28
864	Alarm15	29
865	Alarm16	30
866	Alarm17	31
867	Alarm18	32
868	Alarm19	33
869	Alarm20	34
870	Alarm21	35
871	Alarm22	36
872	Alarm23	37
873	Alarm24	38
874	Alarm25	39
875	Alarm26	40
876	Alarm27	41
877	Alarm28	42
878	Alarm29	43
879	Alarm30	44
880	Alarm31	45
881	Alarm32	46
882	Alarm33	47
883	Alarm34	48
884	Alarm35	49
885	Alarm36	50
886	Alarm37	51
887	Alarm38	52
888	Alarm39	53
889	Alarm40	54
890	Alarm41	55
891	Alarm42	56
892	Alarm43	57
893	Alarm44	58
894	Alarm45	59
895	Alarm46	60
896	Alarm47	61
897	Alarm48	62
898	Alarm49	63

899	Alarm50	64
900	Alarm51	65
901	Alarm52	66
902	Alarm53	67
903	Alarm54	68
904	Alarm55	69
905	Alarm56	70
906	Alarm57	71
907	Alarm58	72
908	Alarm59	73
909	Alarm60	74
910	Alarm61	75
911	Alarm62	76
912	Alarm63	77
913	Alarm64	78
914	Alarm65	79
915	Alarm66	80
916	Alarm67	81
917	Alarm68	82
918	Alarm69	83
919	Alarm70	84
920	Alarm71	85
921	Alarm72	86
922	Alarm73	87
923	Alarm74	88
924	Alarm75	89
925	Alarm76	90
926	Alarm77	91
927	Alarm78	92
928	Alarm79	93
929	Alarm80	94
930	Alarm81	95
931	Alarm82	96
932	Alarm83	97
933	Alarm84	98
934	Alarm85	99
935	Alarm86	100
936	Alarm87	101
937	Alarm88	102
938	Alarm89	103
939	Alarm90	104
940	Alarm91	105
941	Alarm92	106
942	Alarm93	107
943	Alarm94	108
944	Alarm95	109
945	Alarm96	110
946	Alarm97	111
947	Alarm98	112
948	Alarm99	113
949	Alarm100	118
950	Alarm101	119
951	Alarm102	120
952	Alarm103	121
953	Alarm104	122
954	Alarm105	123
955		
956		
957		
958		
959		
960		
961		
962		
963		
964		
965		

966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032

1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099

1100		
1101		
1102		
1103		
1104		
1105		
1106		
1107		
1108		
1109		
1110		
1111		
1112		
1113		
1114		
1115		
1116		
1117		
1118		
1119		
1120		
1121		
1122		
1123		
1124		
1125		
1126	sensorTR8	80
1127	PC0Output	105
1128	PB3Output	106
1129		
1130		
1131	sensorTC3	81
1132		
1133		
1134	sensorTR3	82
1135	sensorTR2	83
1136	sensorTR5	84
1137	sensorTR7	85
1138	sensorJR0Temperature	86
1139	sensorJR2Temperature	90
1140	sensorJR0Pressure	87
1141	sensorJR2Pressure	91
1142		
1143		
1144		
1145		
1146		
1147		
1148		
1149		
1150		
1151		
1152	sensorJR1Pressure	89
1153	sensorJR1Temperature	88

Bosch Thermotechnik GmbH
Sophienstrasse 30-32
D-35576 Wetzlar

www.bosch-thermotechnology.com